
arcutronix

@ccess the Ethernet

USER GUIDE

AMXview



**arcutronix GmbH
Deutschland**

**Installation and
Operation Manual**



AMXview 7.2

Network Management for AMX32

User Manual

Table of Contents

I. HISTORY	4
CHAPTER 1 SYSTEM INSTALLATION AND UNINSTALLATION	1
1.1. SYSTEM CONFIGURE	1
1.2. INSTALL XVIEW SYSTEM	1
1.3. UNINSTALL XVIEW SYSTEM.....	6
CHAPTER 2 SYSTEM HELP	7
2.1. MySQL	7
2.1.1. <i>Install Database</i>	7
2.1.2. <i>Init Database</i>	7
2.2. USE ON THE FLY	8
2.2.1. <i>System Brief Introduction</i>	8
2.2.1.1. System Login.....	8
2.2.1.2. Interface	10
2.2.2. <i>“File” Menu</i>	23
2.2.2.1. Data Export.....	24
2.2.2.2. Data Import	25
2.2.2.3. Delete Alarm Data in Database.....	25
2.2.2.4. Delete Log in the Database.....	26
2.2.2.5. Load MIB.....	27
2.2.2.6. Remote Access to Manager	28
2.2.2.7. Switch to Local Management	29
2.2.2.8. Login	29
2.2.2.9. Cancel Login.....	30
2.2.2.10. Page Setting.....	30
2.2.2.11. Print Topological Graph	31
2.2.2.12. Exit System	31
2.2.3. <i>“Edit” Menu</i>	31
2.2.3.1. View and Edit Properties	32
2.2.3.2. Device Alarm Condition	33
2.2.3.3. Refresh Device List.....	34
2.2.3.4. Search Proxy	34
2.2.3.5. Search Serial Devices	35
2.2.3.6. Cancel Topological Graph Operation	36
2.2.3.7. Redo Topological Graph Operation.....	36
2.2.3.8. Delete Current Device Node	36
2.2.3.9. Delete All Device Nodes.....	36
2.2.4. <i>“View” Menu</i>	37
2.2.4.1. Display Device Topological Graph	37
2.2.4.2. Clear Information in the Trap Alarm Window.....	37
2.2.4.3. Clear Information in the System Log Window	38
2.2.4.4. Clear Information in Http Session Window.....	38
2.2.4.5. Clear Information in Remote Response Window.....	38

2.2.4.6.	Display in Actual Size	38
2.2.4.7.	Zoom Ratio	38
2.2.4.8.	Display Scale	39
2.2.4.9.	Display Boundary.....	39
2.2.4.10.	Display Grid	40
2.2.4.11.	Display Tool Bar.....	41
2.2.4.12.	Display Status Bar.....	41
2.2.5.	<i>“Add” Menu</i>	42
2.2.5.1.	Add Group	42
2.2.5.2.	Add Proxy	43
2.2.5.3.	Desktop Device.....	44
2.2.6.	<i>“Manage” Menu</i>	45
2.2.6.1.	System Account Administration	45
2.2.6.2.	Manage User Groups.....	48
2.2.6.3.	Modify Password.....	53
2.2.6.4.	Start Http Service	54
2.2.6.5.	Stop Http Service.....	55
2.2.6.6.	Set Serial Port	55
2.2.6.7.	Trap Information Management	56
2.2.6.8.	Log Information Management.....	58
2.2.6.9.	Set Poll Time	60
2.2.6.10.	Set Poll Time for Serial Port.....	61
2.2.6.11.	Configure Device Address	61
2.2.6.12.	Set Raisecom-Server Communication Parameters	63
2.2.7.	<i>“Tool” Menu</i>	63
2.2.7.1.	<i>“Select All” and Cancel Select All”</i>	64
2.2.7.2.	<i>“Select Device Primitive” / “Cancel Select Device Primitive”</i>	65
2.2.7.3.	<i>“Select All Connection Lines” / “Cancel Select All Connection Lines”</i>	66
2.2.7.4.	Default Boundary	66
2.2.7.5.	<i>“Optimal Boundary”</i>	67
2.2.7.6.	<i>“Combine” and “Cancel Combine”</i>	67
2.2.8.	<i>“Configure” Menu</i>	68
2.2.8.1.	Background of Topological Graph.....	69
2.2.8.2.	Size of Grid	71
2.2.8.3.	Metric Unit	71
2.2.8.4.	Select Layout	72
2.2.9.	<i>“Window” Menu</i>	74
2.2.9.1.	Maximize Topological Window	74
2.2.9.2.	Minimize Topological Window	74
2.2.9.3.	Cascade Window	74
2.2.9.4.	Current Open Window	75
2.2.10.	<i>“Help” Menu</i>	75
2.2.10.1.	Home Page	75
2.2.10.2.	System Register	76
2.2.10.3.	About	76

2.2.11. Description about Xview Device Operation 77

 2.2.11.1. Desktop Devices 77

CHAPTER 3 ATTENTIONS.....78

3.1. COLORS ON THE TOPOLOGICAL GRAPH 78

3.2. CHOICE OF MODE AND LEVEL OF ALARM 78

3.3. REMOTE ACCESS 78

3.4. ICONS FOR DISPLAYING REPLACED DEVICES 78

I. History

Rev.	Date	Author(s)	Remarks
1.0	28.11.09	AZI	Initial document
1.1	27.09.10	AZI	Changes after Review.

Chapter 1 System Installation and Uninstallation

1.1. System Configure

CPU:	>PM1.0G
Memory:	>256M
Hard Disk:	>100M
Screen Resolution:	>1024*768
Network Adapter:	10M/100M
OS:	Windows98/Windows2000/WindowsXP

1.2. Install Xview System

You may run directly the installation program on the CD, i.e. click install.exe to run the install wizard, and following dialog will appear:




Fig. 1-1

During this process, you may click the "Cancel" button to quit installation. Wait for the progress bar to complete, and following dialog will pop up:



Fig. 1-2

You may click the “Cancel” button to quit installation, or click “Next” button to go on, and then following dialog will appear:





Fig. 1-3

You may click the “Cancel” button to quit installation, or select “I accept the terms in the license agreement” and click “Next” button to go on, and then following dialog will appear:



Xview Network Manager System - InstallShield Wizard

Customer Information

Please enter your information.

User Name:
[]

Organization:
[]

Install this application for:

Anyone who uses this computer (all users)

Only for me (PD)

InstallShield

< Back Next > Cancel

Fig. 1-4

In the dialog box, you may enter your information (User Name and Organization) and select who shall this application install for, and then click “Next” button and following dialog will appear:




Fig. 1-5

In the dialog box, you shall specify the install folder, and then click "Next" button and following dialog will appear:




Fig. 1-6

You may click “Cancel” button to quit installation, or click “Back” button to return to the previous dialog, or click “Install” button to go on installing and following dialog will appear:




Fig. 1-7

You may click “Cancel” button to quit installation. Waiting for the progress bar to complete and following dialog shall pop up:



Fig. 1-8

Click "Finish" button and the installation completes.

1.3. Uninstall Xview System

Run "Uninstall NetworkXView", the following dialog will appear.




Fig. 1-9

Single click "Yes" and following dialog will appear:




Fig. 1-10

Wait for Uninstall to complete.

Chapter 2 System Help

2.1. mySQL

2.1.1. Install Database

Click “Install Database” in the menu to install the database, i.e. “Start” → “All Programs” → “NetworkXView” → “install Database”, and following dialog will appear:



Fig. 2-1-1

The user name and password needed here are all “root”. Enter them and click “OK”, then the database is installed.

2.1.2. Init Database

Click “Init Database” in the menu to initialize the database, i.e. “Start” → “All Programs” → “NetworkXView” → “Init Database”.

2.2. Use on the Fly

2.2.1. System Brief Introduction

2.2.1.1. System Login

Run "Xview" (i.e.: "Start" → "All Programs" → "NetworkXView" → "NetworkXView") to start the system, following login screen will appear:




Fig. 2-2-1-1

Click "ok" and following dialog will appear:



Fig. 2-2-1-2

Click "ok" to continue,

If database has **not** been installed, the following dialog will pop up:



Fig. 2-2-1-3

The setup will not be continued, so you may install the database first (see chapter 2.1).

If database has been installed, the following dialog will pop up:



Fig. 2-2-1-4

Enter correct user name and password in the dialog (initial user name is “admin”, with blank password), then click “OK” to login. If the user name or the password is incorrect, the following dialog will pop up:




Fig. 2-2.1-5

Click “OK” to return to the preview dialog to login; after three false inputs, the system will be terminated. If you want to login, you shall run the program again.

2.2.1.2. Interface

The main window is as follows:




Fig. 2-2-1-6

On top is the Menu Bar as indicated in 2-2-1-7, including: File, Edit, View, Add, Manage, Tool, Configure, Window, and Help.

The letters inside “[]” following each menu are combined shortcut keys, such as “Alt+F” is the shortcut key for File Menu.



Fig 2-2-1-7

The largest window on the right is the window of topological graph, as in the following

example:




Fig. 2-2-1-8

The topological windows are respectively the four branches of

- 1: Nmsc485,
- 2: Other Groups,
- 3: Agent and
- 4: Nms485 and their own device tree topological graphs.

On left side of the main window is wizard region, including list of resources and data of MIB as indicated in Fig. 2-2-1-9:




Fig. 2-2-1-9

The above figure shows the window of tree structure for MIB and in this window related information loaded in MIB can be viewed. For example, Device C04 has 6 nodes as C04_address, C04_port, C04_protmode, C04_byte 1, and C04_byte2. Single click each to view its description. For detailed operation, refer to [File Menu in 2.2.2](#).



Fig. 2-2-1-10

The above figure shows the window of resource list. It lists all the devices for network management in a tree form.

There are three types of devices mainly:

- **desktop devices (refer to 2.2.11 for details),**
- 5U plug-in devices and
- 6U plug-in devices.

Remark: arcutronix GmbH does only offer desktop devices. The 5U- and 6U-plug-in devices are not supported.

Horizontal medium-sized rectangular icon represents desktop agent (agent 1.0/3.0), indicated with letter **D**. The left side of the **D** icon is the local end (L), its right side is the remote end (R), and the traverse line in the middle indicates self.

As indicated in Figure 2-2-1-11.




Fig. 2-2-1-11

Each component of the icons are in four colors: **Red**, **Green**, **Gray**, and **Yellow**, where Red indicates Device Alarm, Green represents Normal, Gray means Offline, and Yellow stands for

Just Added/Waiting for System to Update. **A** has 27 kinds of different effective combinations and **B** has 4 kinds of different combinations. Examples are cited in Figure 2-2-1-12:




Fig. 2-2-1-12

From the above figure, there are altogether 5 device groups Hamburg, Hannover, Berlin, Hannover, and Munich. Take “Hamburg” and “Hannover” as examples. Under “Hamburg” Device Group there are Agents *Agent IV_10.10.0.101 and *Agent II_10.101.0.116”, where the Integration Frame *Nmsc485 is mounted under the “Agent II_10.101.0.116”. The combination of these three items is all in the status of self, local alarm, and remote offline. The devices mounted underneath are all local alarm and remote offline. The Device Group “Hannover” refers to desktop agent “Agent III10.101.0.102” and its combination is in self normal, local and remote alarm status. Device *c16_15 is mounted underneath, and the combination is in a local alarm and remote offline status. Left-click to choose node, or right-click to show the menu and operate accordingly. The pop-up menu is as follows:




Fig. 2-2-1-13

1. Display the device topological graph:

Perform this operation and the network topological graph of the selected device will be shown in the main window, the topological graph is displayed in single layer, and operations such as selection of topological graphs and even boundary points can be performed in the Tool Menu, refer to 2.2.7 Tool Menu for details and it is shown as in Figure 2-2-1-14:




Fig. 2.2-1-14

2. Add a Proxy

If the chosen target is the name of an area group, under the circumstance of having enough privilege, the “Add a proxy” item shall become black (indicating accessibility) and thus you may add a proxy by clicking “Add a proxy” icon, and following dialog shall pop up: After login as Admin or authorized by Admin as an account for adding a proxy, adding a proxy can be operated. Click “Add A Proxy”, the system will pop up the following dialog:




Fig. 2-2-1-15

Operation: Enter the IP address, name, and description of SNMP proxy (shown in the figure), click “Ok”, and the proxy of “Telecom Site No. 1” is added; meanwhile, the content in the resource list will be refreshed, and you may find a newly-added proxy in the list.

3. View or Edit Properties:

Under the circumstances that there is accessibility and this item is effective, here you may view or edit relevant properties of device nodes, proxies, and area groups. You may also double click the mouse for this item and under the circumstances that there is accessibility and this item is effective, you can view or edit relevant properties of device nodes, proxies, and area groups.

The descriptions and names of area groups can be modified; and the descriptions, names and proxy IP addresses of SNMP proxies can be modified; while the descriptions, the local names, the remote names, IP addresses, alarm settings, and other attributes of the ordinary plug-in card devices and desktop devices can be modified.

Refer to “View and Edit Properties” in “Edit” for its operation process.

4. Set Alarm Conditions for this Device:

Here you may view or modify the setting of device alarms. Refer to the operation of “View device alarms” in the “Edit” menu for detailed information.

5. Batch Process Alarm Conditions:

Here you may set or modify alarm status of devices in batches. Click “Batch process of alarm conditions” and following dialog will pop up:




Fig. 2-2-1-16

There are two modes to be selected here:

- 1) Setting alarm level for device under single node; This option is used for setting alarm levels for multiple devices;
- 2). Setting alarm level for single type device.

This option is used for setting alarm levels for a single type of device. This option has at the same time two sub-options: setting of alarm level for existing device and setting alarm level for a new device, the former meaning the setting is only effective to the existing device, while invalid to the newly added type of device, while the latter indicating the setting is valid to the newly added devices of the same type. If both are chosen, then the setting will be valid to all the devices of this type, while if both are not chosen, then this item will be invalid.

There are five alarm levels, i.e.: Treated as no alarm: No action; Hinting alarm: Show information in the alarm column; General alarm: Show information in the alarm column, and save the content of the alarm in database; Serious alarm: Show information in the alarm column, save the content of the alarm in database, and show the device with serious alarm in red in the topological graph.

Click "Ok" button after having selected alarm level; the system will set the alarm property of the device selected and its sub-devices as the level you select.

Click "Cancel" button to return to the main window without any modification.

6. Delete current device node:

Here you may delete selected devices and their sub-devices. Refer to the operation of “Delete current device node” in the “Edit” menu for detailed information.

7. Delete all device nodes:

Here you may delete all device nodes. Refer to the operation of “Delete all device nodes” in the “Edit” menu for detailed information.

8. Refresh Device List:

To re-inspect all connected devices and device nodes set before, and then refresh the resource list.

9. Refresh this proxy:

To re-inspect the properties and connection status of selected proxies.

10. Set temperature threshold:

To set the range of normal temperature of NmsC485 while running. Click “Set temperature threshold” to pop up following dialog:




Fig. 2-2-1-17

Enter an appropriate range of temperature in the dialog (in the format as illustrated, default: 10.0/40.0). Click “Yes” to save the setting, or click “Cancel” to return to the main window without any modification.

The inspection area is at the bottom of the main window, as follows:

When right single-click the mouse to add a new device group and perform “View and Edit Properties”, the following window will pop up as in Fig. 2-2-1-18.




Fig. 2-2-1-18

Single click Distribute Device, the following window pops up as in Fig. 2-2-1-19:




Fig. 2-2-1-19

Select Proxy,

In the same principle, this process is reversible. Select “Beijing Telecom” in the right,

The inspection area is at the bottom of the main window, as indicated in Fig. 2-2-1-20:

Type	Date	Time	Object	From	Information
Minor	2004/06/14	16:43:21:722	*16E1-C_9	192.168.0.101	Remote port 16 alarm
Minor	2004/06/14	16:43:21:712	*16E1-C_9	192.168.0.101	Remote port 15 alarm
Minor	2004/06/14	16:43:21:702	*16E1-C_9	192.168.0.101	Remote port 14 alarm
Minor	2004/06/14	16:43:21:692	*16E1-C_9	192.168.0.101	Remote port 13 alarm
Minor	2004/06/14	16:43:21:682	*16E1-C_9	192.168.0.101	Remote port 12 alarm

Trap alarm System log Http session Remote echo

Fig. 2-2-1-20

Here you may inspect Trap alarm information, system log, connection status of http session, response status during remote management, and debug information of the program.

1. Trap Alarm

Single click “Trap Alarm” to show the above window. And the Trap Alarm item is heaved whereby to view the Trap alarm information. Can also double click” Trap Alarm”, to show the following window:

Type	Date	Time	Object	Source	Information
Minor	2006/06/27	10:46:44:875	Remote name:	127.0.0.1.1.3.6.1.4.1.20660.18.0.0.0.1	Device Offline
Minor	2006/06/27	10:46:44:859	Remote name:	127.0.0.1.1.3.6.1.4.1.20660.17.0.0.0.0	Device Offline

Fig. 2-2-1-21

2. System Log

Single click “System Log” and this item is heaved, to show the following window:

Type	Date	Time	Operator	Information
Add Node	2005/1/2/08	14:27:00:187	admin	Manusly Add Management Device;Remote name:
Alarm Manage	2005/1/2/08	14:25:23:109	admin	Batch Process Alarm Condition
Add Node	2005/1/2/08	14:24:55:453	admin	Adding Device Successful;DevGroup
Alarm Manage	2005/1/2/08	14:22:42:218	admin	Batch Process Alarm Condition
Login/Exit	2005/1/2/08	14:20:05:250	admin	Login success

Trap alarm System log Http Conversation Remote Response

Fig. 2-2-1-22

Thus the system log can be viewed. The above figure shows the log records for device operation and alarm management.

3. Http Session

Single click “Http Session” and this item will be heaved to show the following window:




Fig. 2-2-1-23

There is no display of information as Http service has not yet been started. After Http service is launched in the management menu, the following window appears as follows:




Fig. 2-2-1-24

It can now be seen that this machine has been started as a server. After conditions in the attentions are satisfied, remote company can now login. The accessibilities to local end and remote end are the same, i.e. if the current local end is logged in as an Admin, the remote end is also accessible as an Admin. Likely, if current local end is logged in as an ordinary account, remote end is also accessible with an ordinary account.

Attention: It is not allowed for both ends to login at the same time.

4. Remote Response

Single click "Remote Response and this item is heaved, to show the following window:




Fig. 2-2-1-25

There is no output of information in the window as no user has logged in from the remote end. After a remote login, the following window appears:




Fig. 2-2-1-26

You can see now user with IP of 192.168.0.18 has successfully logged in the system. Operation information such as the access right of the remote computer can be viewed in this window besides login information.

Among the four items of “Trap Alarm”, “System Log”, “Http Session”, and “Remote Response”, only “Trap Alarm” can be double clicked to view the alarm prompt window. However, “System Log”, “Http Session”, and “Remote Response” can be right clicked to show the clear output menu and the output information can be cleared when it is singled clicked.

Besides, there are a series of shortcut icons on the main interface as shown in Fig. 2-2-1-27:



Fig. 2-2-1-27

Mouse can be moved to them to view functions of each icon.

Fig. 2-2-1-27 shows the shortcut icons to be operated in Add Menu.


Take the “” icon in the following figure as an example, you can see there are totally four such icons, representing agent 1.0, agent 2.0, agent 3.0, and agent 4.0, respectively, of which agent 1.0 is desktop agent, agent 2.0 is card agent, agent 3.0 is the upgrade version of agent 1.0, and agent 4.0 is the upgrade version of agent 2.0.



Fig. 2-2-1.28

Attention: agent 2.0 is 6U typed, agent 4.0 is 5U typed, and agent 2.0 cannot be directly used for 5U plug-in devices, but can be under mounted with NMST485, and further be connected into 5U plug-in device from NMST485 to be connected in series parallel. Similarly, agent 4.0 cannot be directly connected to 6U plug-in card device, but can be under mounted with NMSC485 and further connected from NMSC485 into 6U plug-in device for connection in series parallel.




Fig. 2-2-1-29

Remark: arcutronix GmbH does only offer desktop devices. The 5U- and 6U-plug-in devices are not supported.

2.2.2. “File” Menu

“File” menu is as follows:




Fig. 2-2-2-1

2.2.2.1. Data Export

Current information of device nodes in the system is exported here. Its function is to backup the information of device nodes in the system. On the “File” menu, click “Data export”, i.e.: “File” → “Data export”, and following dialog will appear:




Fig. 2-2-2-2

Choose the path for saving in the dialog, enter the name of backup file, and click “save”. If the file has already existed, new information of the node will be saved in the file. If the file doesn't exist, then following dialog will pop up:




Fig. 2-2-2-3

Click “Yes” and Export (Backup) of node information completes.

2.2.2.2. Data Import

To import backup data of device nodes to the system is called data recover (data import), execute “Data import”, i.e. “File” → “Data import”, and following dialog will appear:




Fig. 2-2-2-4

Operation: Choose the path where the backup file is located (as the path in the figure: my document), choose the name of the backup file in the column of file name, click “Open” button. The system will import your backup file into the current system and refresh the resource list of the system.

2.2.2.3. Delete Alarm Data in Database

This function enables managers with enough privilege to manage data in the current database, namely to delete all or part of alarm data. On the “File” menu, click “delete alarm data in the database”, (i.e. “File” → “delete alarm data in the database”); device alarm data in the database will be deleted after confirmation. Data cannot be recovered once it has been deleted, so this operation shall be taken with scrutiny. Following dialog will appear while running:




Fig. 2-2-2-5

Operation: Enter in the dialog the date span for the data to be deleted, input format shall be like yyyy-mm—dd, as (2010-1-21); click “Yes” and following dialog will appear:




Fig 2-2-2-6

Click “Yes” and the system will delete all alarm data in the date span; click “No” and the system will not delete any data but return to the main window. If you want to delete all alarm data, click “Delete all”, and following dialog will pop up:




Fig. 2-2-2-7

Operations here are the same as deleting part of alarm data.

2.2.2.4. Delete Log in the Database

As operation above, this function enables managers with enough privilege to manage data of current database, i.e. delete all or part of log. On the “File” menu, click “Delete log in the database” (i.e. “File” → “Delete log in the database”), all log shall be deleted after confirmation. Data cannot be recovered once it has been deleted, so this operation shall be taken with scrutiny. Following dialog will appear while running:




Fig. 2-2-2-8

Operation: Enter in the dialog the date span for the data to be deleted, input format shall be like yyyy-mm—dd, as (2010-1-21); click “Ok” and following dialog will pop up:




Fig. 2-2-2-9

Click “Yes” and the system will delete all alarm data in the date span; click “No” and the system will not delete any data but return to the main window. If you want to delete all logs, click “Delete all”, and following dialog will pop up:




Fig. 2-2-2-10

The operation here is the same as deleting part of log.

2.2.2.5. Load MIB

MIB refers to MIB information of system device, i.e. OID of devices. On the “File” menu, click “Load MIB” (i.e. “File” → “Load MIB”), following dialog will appear while running:




Fig. 2-2-2-11

Operation: choose path of MIB file to be loaded in the dialog (as the path in the figure: MIB),

choose MIB file name in the file name column, click “Open” button. The system will load MIB file information into current system, meanwhile refresh Tianyuan MIB information list in the system, and display MIB structure information in the “Tianyuan MIB” column. As shown in the following figure:




Fig. 2-2-2-12

Click one node to show relevant MIB property.

2.2.2.6. Remote Access to Manager

Remote access of manager is to login remote computer which runs this program through IP address from local computer for remote inspection. Execute “Remote access to manager” (i.e. “File” → “Remote access of manager”), and following dialog will appear:




Fig. 2-2-2-13

If remote end has started Http service and no firewall is opened, enter in the dialog the correct IP address of the computer you want to login (like: 192.168.0.1), username and password (username and password of remote manager), to connect to remote Manager for remote management.

This function is used for device management on WAN.

2.2.2.7. Switch to Local Management

This function is used with remote login. While you are connecting to remote computer for remote management, "switch to local management" will become black (indicating accessibility), and you may click "Switch to local management" to switch back to manage local devices. Operation: "File" → "Switch to local management", or click the "Switch to local management" icon in the main window to manage local devices.

2.2.2.8. Login

After you have canceled login, "Login" will become black (indicating accessibility). You shall first login before performing any management. On the "File" menu, click "Login", i.e. "File" → "Login", or click the relevant "Login" icon in the main window. Following dialog as indicated in Fig. 2-2-2-14 will appear after you have performed this operation:




Fig. 2-2-2-14

Operation: Enter in the dialog username and password and click "Ok", the system will login to the main window. If the username or password is incorrect, following dialog will appear:




Fig. 2-2-2-15

Click “Ok” to return to login dialog. After three false inputs, the system will be terminated. You shall run the program again to continue.

2.2.2.9. Cancel Login

To cancel login is to logout the current user. Execute “Cancel Login” (“File”→“Cancel Login”, or click relevant “cancel login” icon in the main window) to logout current user. Then any operation of devices cannot be performed, but the system still has not quitted after logout.

2.2.2.10. Page Setting

Page Setting is to set the system for printing the page. Execute “Page Setting” (“File”→“Page Setting”), on the “File” Menu, click “Page Setting” and following dialog will pop up:




Fig. 2-2-2-16

Enter into the dialog items to be set and click “Ok”.

2.2.2.11. Print Topological Graph

To print currently opened topological graph of devices, execute “Print Topological Graph”. Operation: “File” → “Print Topological Graph”, on the “File” menu, click “Print Topological Graph” and following dialog will pop up:




Fig. 2-2-2-17

Choose correct printer and click “Ok”.

2.2.2.12. Exit System

You may perform this operation if you want to exit the system. On the “File” menu, click “Exit the system”, and following dialog will appear:




Fig. 2-2-2-18

Click “Yes”.

2.2.3. “Edit” Menu

“Edit” menu is as follows:




Fig. 2-2-3-1

2.2.3.1. View and Edit Properties

To view or edit properties is to view or edit the properties of device node or proxies. Operation: choose in the resource list the device node or proxies whose property you want to view or edit. You may execute this command if you have sufficient privilege. (“Edit” → “View or Edit Properties”)

For example, choose one proxy and the window is as follows:




Fig. 2-2-3-2

In the basic information column, you may edit property value for the device. To cancel current modification, just click “cancel” button; to confirm current modification, click “Ok” button. Meanwhile the system will return to the main window.

2.2.3.2. Device Alarm Condition

According to the privilege level of its alarm, the device alarm conditions may be divided into 4 categories, that is: Treated as no alarm, hinting alarm, general alarm and serious alarm. Setting device alarm conditions: in the resource list choose the device node or proxy you want to set, as in the case of msc485, execute the command in the menu (“Edit”→”View Device Alarm”) if you have sufficient privilege; or choose in the resource list the device node or proxy you want to set with mouse and then right-click on the item. On the pop-up menu click “Device Alarm Conditions”. Following window as in Fig. 2-2-3-3 will appear while running:




Fig. 2-2-3-3

Herein, the value of every property of alarm may have four choices:

1. Hinting Alarm: While receiving Trap information, display relevant information in the Trap Column on the Inspection Panel.
2. Secondary Alarm: While receiving Trap information, display relevant information in the Trap Column on the Inspection Panel, and besides, save the information into database.
3. Important Alarm: While receiving Trap information, display relevant information in the Trap Column on the Inspection Panel, and besides save the information into database.
4. Urgent Alarm: While receiving Trap information, display relevant information in the Trap

Column on the Inspection Panel, save the information into database, and email the alarm to the system users for them to edit value of alarm property, to cancel the current modification by clicking “Cancel” button, and to accept current modification by clicking “Ok” button. The system will return to the main window at the same time..

If the alarm types set for the devices are the same, you may choose “Batch process of alarm conditions” to perform those operations rapidly. Operation: click the device node or proxy in the resource list, right-click on the item, on the pop-up menu click “Batch process of alarm conditions”, and in the pop-up dialog choose the type and click “Ok”.

2.2.3.3. Refresh Device List

In the resource list choose the device node or proxy you want to refresh, execute the command on the menu (“Edit” → “Refresh Device List”) if you have sufficient privilege; or you may choose the device node or proxy you want to refresh in the resource list and right-click on the item, then click “Refresh Device List” on the pop-up menu. In execution the system shall search automatically devices from SNMP proxy and then display in the resource list for user to perform operations according to the device tree.

2.2.3.4. Search Proxy

To search Proxy is to search proxy within the specified range of IP addresses to determine whether proxies exist or not. Operation: “Edit” → “Search Proxy”, or click on the relevant icon on the main window. Following dialog will appear while running:




Fig. 2-2-3-4

There are two options in the dialog box: 1. Single IP, and 2. Address Field. Select of the former can only modify the initial address, while selection of the latter is to modify both initial address and terminal address. Enter a search range of IP address in the dialog and click “Ok”, the system will enter search process. The following window will appear:




Fig. 2-2-3-5

The proxy system has found will be automatically added into “Other Group” in the resource list at the same time.




Fig. 2-2-3-6

Note: While searching as per address, it is required for the fields of initial address and the fields for the terminal address to be the same, i.e. the addresses for the first three fields are the same and the initial address shall be smaller than the terminal address for the fourth fields.

2.2.3.5. Search Serial Devices

To search serial-port devices is for system to search devices of specified types within the appointed address range. Operation: “Edit” → “Search Serial Device” → Select Device Type and Address Range → Click Search.




Fig. 2-2-3-7

Note: Open serial port prior to searching serial devices.

2.2.3.6. Cancel Topological Graph Operation

To cancel topological graph operation is: When you have any operation on the topological graph, the system will record them, and these operations can be cancelled by executing this command. Operation: “Edit” → “Cancel Topological Graph Operation”, or click on the relevant icon on the main window.

2.2.3.7. Redo Topological Graph Operation

To redo topological graph operation is: when you execute “Cancel Topological Graph Operation”, the system will record them, and the system may redo the operation which was cancelled by executing this command. Operation: “Edit” → “Redo Topological Graph Operation”, or click the relevant icon on the main window.

2.2.3.8. Delete Current Device Node

To delete current device node is to delete specified device nodes or proxies in the resource list, and this command can be executed if you have sufficient privilege.

Operation: Select device nodes or proxies you want to delete, if you have the privilege you may execute the command on the menu (“Edit” → “Delete Current Device Node”); or select the device node or proxy to be deleted, right-click on the item and click “Delete Current Device Node” on the pop-up menu. After confirmation, the system will delete current device node and sub-device nodes; besides, information relevant to the device or its sub-devices in the database will be deleted. So this operation shall be taken with scrutiny.

2.2.3.9. Delete All Device Nodes

To delete all device nodes is to delete all specified device nodes or proxies in the resource list, and this command can be executed if you have sufficient privilege.

Operation: “Edit” →”Delete All Device Node”; or you can right-click on the resource list and click “Delete All Device Nodes” on the pop-up menu. After confirmation, all device nodes and relevant information in the database will be deleted. As in deleting current device node, this operation shall be taken with scrutiny.

2.2.4. “View” Menu

“View ” menu is as follows:




Fig. 2-2-4-1

2.2.4.1. Display Device Topological Graph

Device topological graphs are displayed in single layer, and if the device has sub-nodes, then the topologic relation between the device and its sub-devices will be shown in the topological graph. After selecting certain device nodes, this menu can be executed if you have sufficient privilege.

The topological graph of the device and its first-level nodes will be shown after execution, which is the same as the topological graph in 2.2.1.

2.2.4.2. Clear Information in the Trap Alarm Window

It is the information in the Trap Alarm Window on the Inspection Panel that is to be cleared, but the alarm information in the database will not be cleared. After executing this command with sufficient privilege, you will clear the information in the Trap Alarm Window on the Inspection Panel without any influence on database.

2.2.4.3. Clear Information in the System Log Window

As clearing the information in Trap Alarm window, only information in the system Log Window on the Inspection Panel will be cleared. After executing this command with sufficient privilege, you will clear the information in the system Log Window on the Inspection Panel without any influence on database.

2.2.4.4. Clear Information in Http Session Window

With sufficient privilege, information in Http Session Window on the Inspection Panel will be cleared through the process the same as operations above.

2.2.4.5. Clear Information in Remote Response Window

With sufficient privilege, information in Remote Response Window on the Inspection Panel can be cleared through the process the same as operations above.

2.2.4.6. Display in Actual Size

To show the topological graph in actual size

2.2.4.7. Zoom Ratio

The process here is to set the zoom ratio of device topological graph. Process of operation: "View" → "Zoom Ration" → "Customize", following dialog will appear while running:




Fig. 2-2-4-2

Enter zoom ratio in the dialog, for example 70, and click "Ok", then the topological graph will zoom out to the proportion of 0.7 of its original size. Click "Cancel" and the parameters will not be changed.

There are two other items, "Zoom in" and "Zoom out" in the "Zoom Ratio" menu. These two commands are to zoom in or zoom out the topological graph.

2.2.4.8. Display Scale

After this command is executed, there will be a scale on the topological graph, as shown in Fig. 2-2-4-3:




Fig. 2-2-4-3

2.2.4.9. Display Boundary

Display or hide boundaries of devices on the topological graph. After this command is executed, the topological graph is as follows:




Fig. 2-2-4-4

2.2.4.10. Display Grid

Display or hide grids on the topological graph. The parameters can be modified on “Size of Grid” in “Configure” menu. After this command is executed, the topological graph is as follows:




Fig.2-2-4-5

2.2.4.11. Display Tool Bar

This command is to display or hide the tool bar, which refers to the shortcut key on the main window, and it is a check button. The default status is to display, and the main window in the hidden status is as indicated in Fig. 2-2-4-6:




Fig. 2-2-4-6

2.2.4.12. Display Status Bar

This command is to display or hide the status bar, which refers to the bar at the bottom of the main window, and it is also a check button. The default status is to display, and the main window in the hidden status is indicated as in Fig. 2-2-4-7:




Fig. 2-2-4-7

2.2.5. “Add” Menu

“Add” menu is as follows:




Fig. 2-2-5-1

2.2.5.1. Add Group

The group refers to a device group. In accordance with user’s requirement, devices may be grouped according the region or the characteristic of devices, or no grouping at all (i.e. Don’t use this command).

Operation: “Insert”→”Add Group”, or click on the “Add Group” icon on the main window, and the window is as follows while running:




Fig. 2-2-5-2

Enter a group name and group description in the dialog and click “Ok”, and then a group will be added to the system, meanwhile the resource list will be refreshed. Click “Cancel” to return to the main window without adding any group.

2.2.5.2. Add Proxy

The process of operation for adding proxy: choose the group which the proxy to be added belongs to, and click “Insert” → “Add Proxy”, or click on the “Add Proxy” icon on the main window. The window is as follows while running:




Fig. 2-2-5-3

Operation: Enter the IP address, name and description (as indicated in the figure) of SNMP proxy, click “Ok”, and the adding of “Telecom Site No. 1” completes. Meanwhile, the content in the resource list will be refreshed and you will find a new proxy is added to the resource list.

2.2.5.3. Desktop Device

Desktop devices like AMX32FE (ELAN4000). Take NMS485 as an example, Choose the group which the device to be added belongs to, click on the menu "Add"→"Desktop Device" → "Nms485", or click "Add Nms485" icon on the main window. The following dialog appears while running:




Fig. 2-2-5-10

Enter device address and relevant property into the dialog. The range of address is 0-15, and addresses under the same group should be unique. Click "Ok" after input and thus a NMS485 device is added. Meanwhile, the content in the resource list will be refreshed and you will find a NMS485 device is added to the list. Click "Cancel" to return to the main window without adding a device.

If the address entered is not within the range of 0-15, following dialog will appear after clicking "Ok":




Fig. 2-2-5-11

If the address entered has already existed in the same group, following dialog will appear after clicking "Ok":




Fig. 2-2-5-12

2.2.6. “Manage” Menu

“Manage” menu is as follows:




Fig. 2-2-6-1

2.2.6.1. System Account Administration

Manage user profile is to administrate and set the privilege of system operators. With sufficient privilege, you may execute the commands on this menu (i.e. “Manage” → “Manage user profile”), or click on the “Manage user profile” icon on the main window, and following dialog appears while running:




Fig. 2-2-6-2

To add an account, you only have to click the “Add” button on the dialog, and following dialog shall pop up:




Fig. 2-2-6-3

Enter properties of the account into the dialog of general information, and in those properties, E-mail is to inform the operators through E-mail if an alarm occurs and if the “Send Alarm Mail” is checked.

There are 3 types of system default user groups: Administrator, User/Guest, and Super. The privileges of each user type are not completely the same. Super has the highest privilege and it can execute all operations. The Administrator is the next, and the last is the User. Guest has the lowest privilege.

After filling the general information, you have to set privilege for that account. Click on the “Set Privilege” and following dialog appears as shown in Fig. 2-2-6-4:




Fig. 2-2-6-4

When adding an account, its default privilege is inherited from the group you choose, and there is no need to set privilege under general circumstances. The “Yes/No” column of the dialog indicates the status of privilege correspondingly. A privilege with a “√” indicates the account has that privilege, otherwise no. After selecting relevant privilege, click “Ok” to return to the main window.

If you want to delete an account, first choose the account name in the account list (i.e. move the blue cursor to the account), and then click “delete”. You will find the account is removed from the list, and the deletion of account completes.

If you want to modify the properties of a certain account, first choose the account name in the account list (i.e. move the blue cursor to the account), and then click “Modify” button, and following dialog will appear:




Fig. 2-2-6-5

Following operations are the same as adding an account.

Click "Close" button to close current window to return to the main window.

2.2.6.2. Manage User Groups

Manage user Groups is to administrate and set properties of system operators in groups.

With sufficient privilege, you may execute commands on this menu. (i.e. "Manage"→ Manage User Groups"). Following dialog will appear after execution:





Fig. 2-2-6-6

The operation privileges of Super are as follows:



The screenshot shows a dialog box titled "XView" with two text input fields: "groupname" and "Group desc". Below these fields is a table with two columns: "System function list" and "Yes / No". The table contains 18 rows of system functions, each with a corresponding checkbox in the "Yes / No" column. At the bottom of the dialog box are "Ok" and "Cancel" buttons.

System function list	Yes / No
Clear Data	<input type="checkbox"/>
Export Data	<input type="checkbox"/>
Import Data	<input type="checkbox"/>
Manager Connected to Remote Succ...	<input type="checkbox"/>
View Device Property	<input type="checkbox"/>
Edit Device Property	<input type="checkbox"/>
View alarm Setting	<input type="checkbox"/>
Edit alarm Setting	<input type="checkbox"/>
Auto Detect Device	<input type="checkbox"/>
Search Device	<input type="checkbox"/>
Select Device Node Deletion	<input type="checkbox"/>
Delete All Device Nodes	<input type="checkbox"/>
InsertAgent.M	<input type="checkbox"/>
User Management	<input type="checkbox"/>
Start Http Server	<input type="checkbox"/>
Alarm Information Manage	<input type="checkbox"/>
Log Information Manage	<input type="checkbox"/>
Polling Setup	<input type="checkbox"/>

Fig. 2-2-6-7

The operation privileges of Administrator are as follows:





Fig. 2-2-6-8

The operation privileges of User are as follows:



System function list	Yes / No
Clear Data	<input type="checkbox"/>
Export Data	<input checked="" type="checkbox"/>
Import Data	<input checked="" type="checkbox"/>
Manager Connected to Remote Succ...	<input type="checkbox"/>
View Device Property	<input type="checkbox"/>
Edit Device Property	<input checked="" type="checkbox"/>
View alarm Setting	<input type="checkbox"/>
Edit alarm Setting	<input checked="" type="checkbox"/>
Auto Detect Device	<input type="checkbox"/>
Search Device	<input checked="" type="checkbox"/>
Select Device Node Deletion	<input type="checkbox"/>
Delete All Device Nodes	<input type="checkbox"/>
InsertAgent.M	<input checked="" type="checkbox"/>
User Management	<input type="checkbox"/>
Start Http Server	<input checked="" type="checkbox"/>
Alarm Information Manage	<input type="checkbox"/>
Log Information Manage	<input checked="" type="checkbox"/>
Polling Setup	<input type="checkbox"/>

Fig. 2-2-6-9

The operation privileges of Guest are as follows:




Fig. 2-2-6-10

To add a group, you only have to click “Add” button on the dialog, and following dialog will pop up:




Fig. 2-2-6-11

Enter the name and description of the group to be added and specify its privilege and then click “Ok” to complete.

If you want to delete a group, first choose the group name in the group list (i.e. move the blue cursor onto the group), click “Delete” button, and you will find the group is removed from the group list. The Deletion of group completes.

If you want to modify the property of a group, first choose the group name in the group list (i.e. move the blue cursor onto the group), click “Modify” button, and following dialog will appear:




Fig. 2-2-6-12

Enter new contents into the dialog and click “Ok” to complete modification.

Click “Close” button to close current window and return to the main window.

2.2.6.3. Modify Password

Modify operators' password. All operators can only modify his own password. Execute the command on this menu (i.e. “Manage”→”Modify Password”), and following dialog will appear after execution:




Fig. 2-2-6-13

Enter old password into the dialog, enter twice new password and click “Ok” to complete. If the old password is incorrect, following dialog will pop up:




Fig. 2.2.6.14

Click “Yes” to return to the “Modify Password” Dialog to modify again. If your new password which is entered twice doesn’t match, then your modification of password is unsuccessful, and following dialog will pop up:




Fig. 2-2-6-15

Click “Yes” to return to the “Modify Password” dialog to modify.

2.2.6.4. Start Http Service

With sufficient privilege, you may execute commands on this menu. After you set an appropriate port number, Http service can be started. (i.e. “Manage” → “Start Http Service”), and following window will appear:




Fig. 2-2-6-16

Enter port number, whose default value is 80, for Http service into the dialog, click “Ok” button, then the system return to the main window and Http service is started. Meanwhile the Http Session is displayed as follows:




Fig. 2-2-6-17

While accessing Http service, you may visit through IP address, for example, if the port of local computer is 8080, then use <http://127.0.0.1:8080> to visit local computer. If the default port is used, then use <http://127.0.0.1>

2.2.6.5. Stop Http Service

If you want to stop Http service which has been started, with sufficient privilege, you may execute the command on the menu (“Manage”→”Stop Http Service”), and then Http service is stopped. At the same time, the Http Session is displayed as follows:




Fig. 2-2-6-18

2.2.6.6. Set Serial Port

To set serial port includes: open serial port, close serial port, set parameters for serial port,

and search all serial ports in the system. Following dialog will appear after executing the command on the menu (i.e. “Manage” → “Set Serial Port”):




Fig. 2-2-6-19

Enter the name and properties of the serial port into the dialog, as illustrated in the figure above, the serial port has not been opened. Having set the properties, click “Open Serial Port” and then the port is opened, meanwhile, “Open Serial Port” button becomes gray (indicating inaccessibility), while the “Close Serial Port” button becomes black (indicating accessibility), as indicated in the following figure:




Fig. 2-2-6-20

The serial port illustrated in the figure above indicates that the port is opened, if you want to close the port, just click “Close Serial Port” button and the port is closed. Meanwhile, the “Close Serial Port” button becomes gray (indicating inaccessibility), while the “Open Serial Port” becomes black (indicating accessibility), as illustrated in the picture before this one. If the port is in open status and you want to reset the properties of it, just click “Apply” after you have entered parameters into the dialog.

Only when the port is in open status can new devices of serial port be added, no operation of devices of serial port can be taken when the port is closed.

2.2.6.7. Trap Information Management

Trap Information Management is to search, print or delete alarm information when the device is in use. Execute the command on this menu (i.e. “Manage” → “Trap Information Management”) and following dialog will appear:

Tra...	warning oid	Trap device na...	Trap date	Trap content
4693	192.168.0.101.1.3.6.1.4....	*16E1-C_9	2004/06/14 16:48:33:551	*16E1-C_9 down
4692	192.168.0.101.1.3.6.1.4....	*8E1-C_1	2004/06/14 16:48:33:461	*8E1-C_1 down
4691	192.168.0.101.1.3.6.1.4....	*NmsC485	2004/06/14 16:48:33:451	*NmsC485_0 down
4690	192.168.0.101.1.3.6.1.4....	*16E1-C_9	2004/06/14 16:48:33:200	Start...
4689	192.168.0.101.1.3.6.1.4....	*NmsC485	2004/06/14 16:48:17:698	*NmsC485_0 down
4688	192.168.0.101.1.3.6.1.4....	*16E1-C_9	2004/06/14 16:46:32:987	*16E1-C_9 down
4687	192.168.0.101.1.3.6.1.4....	*8E1-C_1	2004/06/14 16:46:32:997	*8E1-C_1 down
4686	192.168.0.101.1.3.6.1.4....	*NmsC485	2004/06/14 16:46:32:987	*NmsC485_0 down
4685	192.168.0.101.1.3.6.1.4....	*16E1-C_9	2004/06/14 16:46:25:957	Remote port 16 alarm
4684	192.168.0.101.1.3.6.1.4....	*16E1-C_9	2004/06/14 16:46:25:947	Remote port 15 alarm
4683	192.168.0.101.1.3.6.1.4....	*16E1-C_9	2004/06/14 16:46:25:947	Remote port 14 alarm
4682	192.168.0.101.1.3.6.1.4....	*16E1-C_9	2004/06/14 16:46:25:937	Remote port 13 alarm
4681	192.168.0.101.1.3.6.1.4....	*16E1-C_9	2004/06/14 16:46:25:927	Remote port 12 alarm
4680	192.168.0.101.1.3.6.1.4....	*16E1-C_9	2004/06/14 16:46:25:927	Remote port 11 alarm
4679	192.168.0.101.1.3.6.1.4....	*16E1-C_9	2004/06/14 16:46:25:917	Remote port 10 alarm
4678	192.168.0.101.1.3.6.1.4....	*16E1-C_9	2004/06/14 16:46:25:917	Remote port 9 alarm
4677	192.168.0.101.1.3.6.1.4....	*16E1-C_9	2004/06/14 16:46:25:907	Remote port 8 alarm
4676	192.168.0.101.1.3.6.1.4....	*16E1-C_9	2004/06/14 16:46:25:897	Remote port 7 alarm
4675	192.168.0.101.1.3.6.1.4....	*16E1-C_9	2004/06/14 16:46:25:887	Remote port 6 alarm
4674	192.168.0.101.1.3.6.1.4....	*16E1-C_9	2004/06/14 16:46:25:887	Remote port 5 alarm
4673	192.168.0.101.1.3.6.1.4....	*16E1-C_9	2004/06/14 16:46:25:877	Remote port 4 alarm
4672	192.168.0.101.1.3.6.1.4....	*16E1-C_9	2004/06/14 16:46:25:867	Remote port 3 alarm
4671	192.168.0.101.1.3.6.1.4....	*16E1-C_9	2004/06/14 16:46:25:867	Remote port 2 alarm
4670	192.168.0.101.1.3.6.1.4....	*16E1-C_9	2004/06/14 16:46:25:857	Remote port 1 alarm
4669	192.168.0.101.1.3.6.1.4....	*16E1-C_9	2004/06/14 16:46:25:847	Local port 16 alarm
4668	192.168.0.101.1.3.6.1.4....	*16E1-C_9	2004/06/14 16:46:25:847	Local port 15 alarm
4667	192.168.0.101.1.3.6.1.4....	*16E1-C_9	2004/06/14 16:46:25:837	Local port 14 alarm
4666	192.168.0.101.1.3.6.1.4....	*16E1-C_9	2004/06/14 16:46:25:837	Local port 13 alarm
4665	192.168.0.101.1.3.6.1.4....	*16E1-C_9	2004/06/14 16:46:25:827	Local port 12 alarm
4664	192.168.0.101.1.3.6.1.4....	*16E1-C_9	2004/06/14 16:46:25:817	Local port 11 alarm

Fig. 2-2-6-21

Alarms the system find when it first enters are all alarms.

If you want to inquire about the alarm data of a certain device or within a certain period of time, you may click on the “Set Condition” button on the dialog, and following dialog will pop up:

Set trap filtrate condition

Alarm Device Name: All Devices

Alarm Start Date: 2003/01/01 00:00:00

Alarm End Date: 2005/12/08 15:10:00

Alarm Order: Alarm ID

trap Content:

Ok [O] Cancel [C]

Fig. 2-2-6-22

In the dialog above, all names of alarm devices includes the name of all devices and devices that are detected by the system or added manually. Alarm Sorting refers to the sorting method used after data has been inquired, including Serial number, Name of Alarm Device, and Content, etc. Enter inquiring condition and click “Ok” and then corresponding data will be shown in the dialog of Administration of Alarm Information.

Refresh is to search and display data according to the condition specified.

If you want to delete certain alarm data, select data to be deleted in the data column, (Multiple selections is allowed: Holding “Shift” Key, click with the mouse or use the up/down arrow on the keyboard to select.) After you have selected those data, click “Delete”. Data deleted

cannot be recovered, so this function shall be used with scrutiny.

Preview is to preview the printing page. The window is displayed as follows:




Fig. 2-2-6-23

You can click “Next Page” and “Previous Page” to view the printing content.

Print is to submit data in the list to the printer for printing.

Close this operation and return to the main window.

2.2.6.8. Log Information Management

Log is log information recorded when operators do any modification or important operation to the data of Xview Manager. Execute this command on the menu (“Manage” → “Manage Log”), and following dialog will appear:




Fig. 2-2-6-24

The window above shows all Log of the system, if you want to inquire above relevant log, click “Set Condition” and following dialog will appear:




Fig. 2-2-6-25

Choose username, time and sorting method in the dialog. Herein username and time is to stipulate the range of log, while sorting is to stipulate the sorting method for sorting information inquired. Click “Ok” and a dialog appears which is analogous to the previous and may only differ in contents and their sorting methods.

Refresh is to display data which is found according to the condition newly set.

If you want to delete certain log information, choose data in the data list. (Multiple selections is allowed: Holding “Shift” Key, click with the mouse or use the up/down arrow on the keyboard to select.) After you have selected those data, click “Delete”. Data deleted cannot

be recovered, so this function shall be used with scrutiny.

Preview is to preview the printing page. The window is displayed as follows:




Fig. 2-2-6-26

You may click “Next Page” and “Previous Page” to view the printing content.

Print is to submit data in the list to the printer for printing.

Close this operation and return to the main window.

2.2.6.9. Set Poll Time

Poll time is the cycle of polling devices while running. Execute the command on the menu (“Manage”→”Set Poll Time”), and following dialog will appear:




Fig. 2-2-6-27

As there is a discrepancy in the time actually needed for polling a round of devices, the interval of polling time shall be set a bit larger than suggested (the suggested value is more than 240s). Enter the data and click “Ok” to start polling in accordance with the configuration. Click “Cancel” to cancel current modification, and the system shall poll with its original cycle.

Note: Polling interval must be larger than 5 seconds.

2.2.6.10. Set Poll Time for Serial Port

Poll time for serial port is the cycle of serial ports while running. After serial port is opened, this Menu becomes black (indicating accessibility). Execute this command on the menu (i.e. "Manage" → "Set Poll Time for Serial Port", following window appears:




Fig. 2-2-6-28

The entered numbers must be integers, and click "Confirm after data is entered, to start polling according to this time. Click "Cancel" to cancel the current setting. System polls serial ports as per original cycle.

2.2.6.11. Configure Device Address

After serial port is opened, this Menu turns black (indicating accessibility). With enough privilege, you may connect the device AMX32FE (ELAN4000) with serial port of the local computer. Following window appears after this command on the menu (i.e. "Manage" → "Configure Device Address") is executed:




Fig. 2-2-6-29

First read the default address of the connected device, and then set its address. This option is used for network management software to set address of the device, but this is only valid to device whose address can be set by the software.

If the serial port has not been connected with AMX32FE (ELAN4000), click "Read Address" at this point, and following dialog will appear:




Fig. 2-2-6-30

Dial down firstly the DIP [S/H] switch of AMX32FE (ELAN4000), indicating this device is controlled by the software, and then connect AMX32FE (ELAN4000) with serial port of local computer, the baud rate of the serial port set as 19200, as shown in the following window:




Fig. 2-2-6-31

Now you may again click “Read Address” to show the following dialog:




Fig. 2-2-6-32

Read is successful. Click “Ok” to see the default address of AMX32FE (ELAN4000) as 0. The Address Bar now has turned white, indicating accessibility.

Finally, you may set the address of device AMX32FE (ELAN4000) simply by entering one integer of 0-15 into the Address Bar of the device, as indicated in Fig. 2-2-6-33:




Fig. 2-2-6-33

If there is no conflict, the following dialog will appear:




Fig. 2-2-6-34

Setting the address of device AMX32FE (ELAN4000) now completes.

2.2.6.12. Set Raisecom-Server Communication Parameters

Raisecom-Server is used by local terminal to pass user shared data for network manager connection between local end and client end.

After this command on the menu (i.e. "Manage" → "Set Raisecom-Server Communication Parameters") is executed, the following window will appear:




Fig. 2-2-6-35

This option is used for setting communication parameters of Raisecom-Server.

2.2.7. "Tool" Menu

"Tool" menu is as follows:






 Select all	Ctrl+A
Unselect all	Ctrl+D
Select Device Primitives	Ctrl+Shift+V
UnSelect Device Primitives	
Select all connection	Ctrl+E
UnSelect all connection	Ctrl+Shift+E
 Default Border Points	Ctrl+Shift+D
 Optimal Border Points	Ctrl+Shift+B
 Combination	Ctrl+G
 Uncombination	Ctrl+U

Fig. 2-2-7-1

Topological graph is composed of device primitives and connection lines. All operations in the “tool” menu are targeted on the topological graph. They can be used to reform or move the topological graph as you need.

2.2.7.1. “Select All” and Cancel Select All”

Topological graph is as follows:



Fig. 2-2-7-2

Execute “Select All” or click shortcut key “Ctrl+A” to select all the primitives in the topological graph currently active, and all the device primitives and connection lines will be selected as in Fig. 2-2-7-3:




Fig. 2-2-7-3

Execute “Cancel Select All” or click the part outside the device primitives and connection lines in topological graph, to cancel select all of the primitives in the topological graph currently active, and all the device primitives and connection lines will be in the status of not selected. Topological graph returns into original status.

2.2.7.2. “Select Device Primitive” / “Cancel Select Device Primitive”

Execute “Select Device Primitive” to select device primitives in topological graph currently active, and all device primitives will be selected as indicated in Fig. 2-2-7.4:




Fig. 2-2-7-4

Execute “Cancel Select Device Primitive” or click the part outside the device primitives and connection lines in the topological graph is to cancel select device primitives in the topological graph currently active, and all device primitives will be in the status of not selected. The topological graph returns into the original status.

2.2.7.3. “Select All Connection Lines” / “Cancel Select All Connection Lines”

Execute “Select All” to select all primitives in the currently active topological graph, and all the connection lines will be selected, as in Fig. 2-2-7-5:




Fig. 2-2-7-5

Execute “Cancel Select All” or click the part outside the primitives and connection lines in the topological graph is to cancel select all primitives in the currently actively topological graph, and all the connection lines will be in the status of not selected. The topological graph returns into the original status.

2.2.7.4. Default Boundary

After selecting topological graph, execute “Default Boundary” to show the following topological graph:



Fig. 2-2-7-6

2.2.7.5. “Optimal Boundary”

After selecting topological graph, execute “Optimal Boundary” to show the following window:



Fig. 2-2-7-7

The above figure indicates that all the devices belong to set frame NMSC485 are offline.

2.2.7.6. “Combine” and “Cancel Combine”

After selecting topological graph, execute “Combine to show the following window:




Fig. 2-2-7-8

After selecting topological graph, execute “Cancel Combine” to show the topological graph as in Fig. 2-2-7-9:




Fig. 2-2-7-9

2.2.8. “Configure” Menu

“Configure” menu is as follows:




Fig. 2-2-8-1

Functions above can be applied to set the background of the topological graph, grid size, grid unit, layout of the program etc.

2.2.8.1. Background of Topological Graph

There are three options with background of topological graph:

- Color,
- Picture and
- Without Picture.

1) Color

This option is used for changing background color of topological graph. It has three setting methods:

① Sample

This option provides us with a series of hues for our selection.




Fig. 2-2-8-2

② HSB.

This option can allow us for precision setting of background color.




Fig. 2-2-8-3

③ RGB.

Analogous to the second item, this option allows us to precision set background color, and what differs is only the different setting method.




Fig. 2-2-8-4

2.2.8.2. Size of Grid

This option is to change the size of grid in “Display Grid” in the “View” menu. You have only to execute “Size of Grid”, and following dialog will pop up.




Fig. 2-2-8-5

Then enter numbers in the “Size” bar, and click “Ok”.

2.2.8.3. Metric Unit

This option is used for selecting display mode of topological graph. This menu is only valid when the topological graph is shown with scale. When “Metric Unit” is not selected, topological graph is displayed as in Fig. 2-2-8-6:



Fig. 2-2-8-6

After this command on the menu is executed, Fig. 2-2-8-7 is displayed:



Fig. 2-2-8-7

All the decimal digits appear no more now, and what's shown are all integer numbers.

2.2.8.4. Select Layout

There are three types of selection for layouts as Metal Layout, CDE/Motif, and Windows.

1) Metal Layout.

Shown as follows:




Fig. 2-2-8-8

2) CDE/Motif.

Displayed as follows:




Fig. 2-2-8-9

3) Windows.

Indicated as below:




Fig. 2-2-8-10

2.2.9. “Window” Menu

“Window” Menu is as follows:




Fig. 2-2-9-1

2.2.9.1. Maximize Topological Window

This option enables to maximize the active topological window.

2.2.9.2. Minimize Topological Window

This option enables to minimize the active topological window.

2.2.9.3. Cascade Window

This option enables the open topological window in cascade, as indicated below:




Fig. 2-2-9-2

2.2.9.4. Current Open Window

Indicate the opened topological window.

2.2.10. “Help” Menu

“Help” menu is as follows:




Fig. 2-2-10-1

2.2.10.1. Home Page

Home page refers to the homepage of the developer of this system. Click and visit the site.

2.2.10.2. System Register

Register is to obtain the right to use this system. For example, if the system is installed for the first time in a new environment, it needs to be registered for normal use. Process of Registration: Click "Help" → "System Register", and following dialog will appear after that:




Fig. 2-2-10-2

Enter Register Name and Register Code in the dialog and click "Ok". Register Name and Register Code here are all provided by the developer of the system. If the input is incorrect, following dialog will pop up:




Fig. 2-2-10-3

Enter the correct Register Name and Register Code, following dialog will pop up:




Fig. 2-2-10-4

Click "OK" to complete register.

2.2.10.3. About

You may inquire about the version information of the software here. Click "Help" → "About", to show the following window:



Fig. 2-2-10-5

2.2.11. Description about Xview Device Operation

2.2.11.1. Desktop Devices

2.2.11.1.1. AMX32FE (ELAN4000)




Fig. 2-2-11-19

You may edit the property value (i.e. the content displayed in blue color in the “Current Value” column). Click “Cancel” button, to cancel current modification, while click “Ok” button to accept current modification. The system will return to main window at the same time; while “Apply is to apply the current modification into system, but it is not confirmed of cancelled, and will not return to main window.

Chapter 3 Attentions

3.1. Colors on the Topological Graph

Off Line: **Gray**

Alarm: **Red**

Normal: **Green**

Device newly added to be updated by system: **Yellow**

3.2. Choice of Mode and Level of Alarm

Not as alarm: No action;

Prompting alarm: Show information in the alarm column;

General alarm: Show information in the alarm column, and save the content of the alarm in database;

Serious alarm: Show information in the alarm column, save the content of the alarm in database, and show the device with serious alarm in red in the topological graph.

3.3. Remote Access


When operating remote access, firstly open the Http Service for the local computer, and you shall not open any firewall, including the firewall of Windows itself. Login is only unilateral and it is not allowed for mutual access.

3.4. Icons for displaying Replaced Devices


 **DeviceTree** Represents Device Tree for the entire network.

 Represents One Device Group.

 Represents an Integration Box (Agent or Other Network Boards)

 Represents Desktop Agent

 Represents Desktop Device

 Represents card device

Refer to Descriptions about Devices in Description about Windows.

Headquarter

arcutronix GmbH
Garbsener Landstrasse 10
30419 Hannover
Germany

Phone: +49 (511) 277 2700
Fax: +49 (511) 277 2709
EMAIL: info@arcutronix.com
www.arcutronix.com